



## Gunshot Residue (GSR) on hands

### Securing gunshot residues using aluminium stubs

(electron-microscopic examination):

Remove the protective film from the stub with the help of forceps and swab hand with adhesive film on aluminium stub, store the stub safely after swabbing.

### REM-Box

Kit consists of:

10 aluminium stubs with electrically conductive adhesives,

10 individual packaging (transparent tube with sealing push-in cap)

10 labels

Cat.No.	Description	Unit
47883	REM-Box, kit of 10 units	1 kit
	For an order of 10	1 kit
	For an order of 20	1 kit
	For an order of 30	1 kit

## Component Parts

### Aluminium Stub

Cat.No.	Description	Unit
47880	Aluminium Stub	100 sheets 1 package

### Electrically Conductive Adhesives

adhesive on both sides, good electrical conductivity, blanked out film disk, covered on both sides with plastic foil, used to adhere on aluminium stubs

Cat.No.	Description	Unit
47882	Electrically Conductive Adhesives	100 sheets 1 package

### Aluminium Stub, individually packed

transparent tube with sealing push-in cap for transport and storage of residues on aluminium stubs

Cat.No.	Description	Unit
47881	Individual Packaging for aluminium stub	10 sheets 1 package

## Gunshot Residues Securing-Kit for investigation of suicides

contents:

2 pairs of disposable gloves, DNA-free

2 REM adhesive stamp

2 Neschen lifting film Filmolux S23

1 safe bag, EO-treatment

4 labels gunshot residue

1 overhead marker

Cat.No.	Description	Unit
50918	Burn Marks Securing Kit for examination of suicide	1 kit

**Neschen Lifting Tape for collecting gunshot residues is on page 39!**